



ASSEMBLY INSTRUCTIONS:

- 1) Install lock bracket (Item 3) using self tapping screws (Item 4) into existing holes on side.
- 2) Install hinges (Item 2) on door (Item 1), ensure hinge pins are located with bent arm at the top.
- 3) Hinges are designed to simply "Snap" into cabinet frame. Push firmly to ensure hinges snap in fully.

PARTS LIST		
ITEM No.	DESCRIPTION	QTY
1	PERFORATED DOOR	1
2	SNAP IN HINGE	2
3	LOCK BRACKET	1
4	8-32 X 3/8" SELF TAP SCREWS	2

TOOL BOX



Phillips
Screw Driver



**HAMMOND
MANUFACTURING™**
ELECTRONICS GROUP

visit our website @ www.hammondmfg.com